# AMAZON FIRE STICK REMOTE GUIDE

#### Power-

Turns your TV On & Off

## Navigation-

Press up, down, left and right to move your curser in those directions. The option you're on is highlighted by color or size.

#### Back-

Returns you to the previous screen.

# **Playback Controls-**

Control live TV and your video recordings using the video control buttons.

# -Microphone & -Voice Button

Allows you to use voice commands, like "Open Dakota Central TV app" or to search within the Dakota Central TV app.

#### Select

Selects highlighted screen options.

### Home

Returns you to the Fire Stick Home menu.

#### Menu

П×

Gives you access to the features of your Dakota Central TV service.

**Volume Control** 

-Mute Audio